



**Fax:** 07 5514 0514

**Mob:** 0411 872 000

[www.profender.net.au](http://www.profender.net.au)

[sales@profender.net.au](mailto:sales@profender.net.au)

## FITTING INSTRUCTIONS FOR D-FENDER

1. Where Fender is being fitted on a Marina Berth or Pontoon with existing rubber gunnel remove all.
2. Lay out Fender Cover and Fill with D-Foams (*see photo 1*)  
Start at one end and flex foams in so as the foams are squashed in (for example 1.1 meters of foam for every 1 meter of cover) this will prevent shrinking of the foam over any length of time.  
**NB:** Where your Fender goes around a corner same procedure applies fit the corner in and work away from it flexing the foams as you do up the Zip.
3. Fit one length of your sail track 90mm down from the top edge of the pontoon with the rope section at the bottom. (*see photo 2*) track requires screws to be fitted every 500mm.  
**NB:** When going around corners this track will finish 500mm from the end to allow the fender to be slid into the track.
4. Once the bottom Track is completed lay the fender in the water and feed the lower rope on the fender into the sail track. (*see photo 3*) (When your fender has a corner fit the longest side first).
5. Once your Fender is in place slide the top Sail Track onto the fender and pull it onto the pontoon and fix every 500mm (*see photo 4*) once this is completed close the ends of the track to stop the fender sliding (*see photo 5*)

Congratulations your new D-Fender is fitted Happy Boating!



1. Fitting Fender Cover with D-Foams



2. Fitting Lower Aluminum Sailtrack



3. Sliding D-Fender Into lower Sailtrack



4. Fitting top Sailtrack onto Fender



5. Closing Ends of Sailtrack



6. Your Completed D-Fender